



PLACE THE FIREBACK ON THE FEET. INSERT WEDGE WITH TEXTURED SIDE AGAINST FOOT AND BLANK SIDE AGAINST THE FIREBACK. SLIDE THE WEDGE DOWN TO SECURE THE FIREBACK (TAP IT IN IF NEEDED)