

READ AND SAVE THESE INSTRUCTIONS

EVERDURE



**OPERATION, MAINTENANCE
AND SAFETY INSTRUCTIONS**

EPPREPSTAND



Scan for
further support

Due to ongoing product development, images shown are subject to change without warning

CONTENTS

Important Safety Instructions	3
Appliance Details	3
Cleaning & Storage	4
Parts List.....	5
Assembly	6-16
Warranty	16

Note: In this instruction manual, the Everdure pizza station will be referred to as an appliance.

Read these instructions and follow steps carefully to ensure you assemble the appliance correctly and avoid damages. Check that all parts and hardware have been provided before assembling the appliance. Place all contents on a clean, soft-flat surface to avoid scratching the product.

IMPORTANT SAFETY INSTRUCTION:**WARNING:**

- **DO NOT** climb, step, or stand on the appliance or in the drawer.
- **DO NOT** use the appliance for any purpose other than that for which it is designed.
- **DO NOT** exceed the maximum weight for drawer 22.5kg (50lbs).
- Keep the appliance on a level surface. It may become unstable if stored or moved on a sloping surface and may cause personal injury, and/or damage to the appliance.
- Always apply the brakes once the appliance has been moved to the area.
- To prevent damage to threads, do not use a power tool and do not overtighten screws.
- Use two people to lift and to turn the appliance when assembling.
- Do not attempt assembly with one person.
- Keep all hardware and small parts away from children.
- When moving the appliance secure any items placed on top to prevent damage or personal injury.

APPLIANCE DETAILS:

EPPREPSTAND	LENGTH mm (in)	WIDTH (in)	HEIGHT (in)	WEIGHT kg (lb)
	1400 (55.11)	650 (25.19)	965 (37.99)	80 (176.36)

FIRST TIME USE:

Please wash by hand the stainless-steel top with small amount of soap and warm water before using for the first time. Don't forget to sanitise the surface area before use.

CLEANING / SANITISING

Cleaning is the process of using a detergent and water to remove residual food matter, dust, grease, dirt, stains and smelly odours from all surfaces, fixtures, utensils, and equipment.

Sanitising is the process of killing food poisoning bacteria by using heat and/or chemicals. This process must be used on food contact surfaces so that the number of bacteria is reduced to a level that is safe for food contact and does not allow infectious diseases to be passed on.

1. Remove dirt and food by sweeping, scraping, wiping, or rinsing with water.
2. Wash Use warm water and detergent.
3. Rinse off detergent and any remaining food or dirt.
4. Sanitise to eliminate/reduce microorganisms to safe levels.
5. Final Rinse off sanitiser if needed.
6. Dry Air dry or use a single use towel or clean tea towel.

! Cleaning and Sanitising are generally separate processes. A surface should be thoroughly cleaned before sanitising. Sanitising is not as effective if a surface is still dirty, or detergents are still present.


STORAGE:

When the appliance is not in use, it can be stored outdoors, but **MUST** be under cover and covered (preferably with a purpose made cover) out of the weather ensuring the cutting surfaces are clean and dry before storing away.

PACKAGING:

- Remove all external packaging and remove the appliance from the packaging before use.
- Removal all internal cartons and packaging from within the appliance assembly.
- Recycle as per local government laws

PARTS LIST:



NO.	Part Name	QTY	PCS
1	Table top	1	PCS
2	Table top support	1	PCS
3	Back panel	1	PCS
4	Left panel	1	PCS
5	Middle panel from left	1	PCS
6	Center drawing plate	4	PCS
7	Drawer	1	PCS
8	Center drawing plate	1	PCS
9	Right drawing plate	1	PCS


NO.	Part Name	QTY	PCS
11	Base panel	1	PCS
12	Left side door hook	1	PCS
13	Right panel	1	PCS
14	Mini -box	5	PCS
15	Drawer plate baffle	2	PCS

Please contact everdure.com for any spare part related inquires.

Assembly, Operation & Maintenance Instructions

Step 1:


Connect part ③ to the back side of part ⑪ with (A)E*3pcs



Assembly, Operation & Maintenance Instructions


Step 2:

Connect part (10) to the right side of part (11) with (A)(E)*2pcs



Step 3:



Connect part (4) to the left side of part (11) with (A)(E)*2pcs



Assembly, Operation & Maintenance Instructions



Step 4:

Connect part (8) to the right side of part (3)(11) with (C)(E) *5pcs



Step 5:


Connect part (5) to the right side of part (3)(11) with (C)(E) *5pcs



Assembly, Operation & Maintenance Instructions


Step 6:


Connect part ② to the top side of part ③④⑤ with ①⑤*11pcs




Step 7:

Connect part ⑥ *4pcs to the inner side of part ⑤⑧ with ⑦④*16pcs






Step 7:
Connect part ⑥ *4pcs to the inner side of part ⑤⑧ with ②④ *16pcs



Step 8:

Insert part ⑨ *2 to the inner side of part ⑩ ⑧





Step 9:

Insert part ⑦ to the inner side of part ⑤ ⑧

Assembly, Operation & Maintenance Instructions

Step 10:


Connect part ⑮ *2 to the middle side of part ③ with ④② *6pcs



Assembly, Operation & Maintenance Instructions

Step 11:


Connect part ⑫ to the front side of part ④ with ⑩*4 pcs



Assembly, Operation & Maintenance Instructions


Step 12:

Connect part 13 to the front side of part 10 with D*4 pcs




Assembly, Operation & Maintenance Instructions

Step 13:
Insert part ⑭*5 to part ①



Step 14:
Insert part ① to part ②



EVERDURE

FIVE YEAR CONDITIONAL WARRANTY

This warranty applies to the original purchaser of the appliance in the United States. This warranty shall commence on the date of purchase and shall terminate (both as to the original and any repair or replacement) on the anniversary date of the original purchase of the appliance at the end of the warranty period. You must retain your proof of purchase for service or repairs claims under this warranty.

WHAT IS COVERED

SHRIRO USA INC. warrants our appliance to be free from defects in material and workmanship under normal non-commercial, household use when operated and cared for as per the provided Manufacturer's written instructions.

If the appliance fails at any time within time frame below of the original purchase date due to a defect in materials or workmanship, subject to the terms and conditions of this warranty, we will repair or replace the defective part free of charge. Any replacement parts issued are covered by the time remaining on the original Five-year conditional warranty.

- Frame Five years
- Stainless steel Two years
- Paint finish Two years
- Other parts One year

WHAT IS NOT COVERED

This warranty does not apply to defects resulting from abuse of the appliance. Abuse of the appliance may include mishandling, improper appliance use, commercial use, modification, alteration, repair, or service by anyone other than SHRIRO USA INC. or its authorized service agents. Support services or appliance warranties will not cover transportation damages, failure resulting from power surges and electrical storms, insect or vermin infestation, surface rust, discolouration, heat tarnishing, stone cracking due to improper use (i.e. thermal cracking), Severe weather conditions such as hail, acid rain, hurricanes, earthquakes, wildfires, tsunamis or surges, tornadoes or severe storms and other environmental factors, exposure to water, salt air and/or chlorine sources such as swimming pools and hot tubs/spas, and other consequences. This warranty excludes liability for consequential, indirect, or incidental damage resulting from appliance use or breach of this warranty. Some states do not allow for the exclusion or limitation of consequential, indirect, or incidental damage, to the extent that this exclusion or limitation is not permitted by law it shall not apply. This means that the above exclusion may not apply to you.

THIS WARRANTY IS EXCLUSIVE AND IN PLACE OF ALL OTHER EXPRESS WARRANTIES. TO THE EXTENT PERMITTED BY LAW, SHRIRO USA INC. DISCLAIMS ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR USE OR PURPOSE; TO THE EXTENT SUCH DISCLAIMER IS NOT PERMITTED BY LAW, SUCH IMPLIED WARRANTIES ARE LIMITED TO THE DURATION OF THE APPLICABLE EXPRESS WARRANTY AS DESCRIBED ABOVE. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU, THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

CONTACT US

To obtain repairs under this warranty, call Toll Free +1 877 794 2622 or email, service@everdure.com

For prompt service, please ensure you have the following information on hand:

1. Appliance Name/Model Number
2. Serial Number
3. Purchase Date (as per invoice or proof of purchase)
4. Purchased from

SHRIRO USA INC. Incorporation Number 7164875
 25541 Arctic Ocean Drive
 Lake Forest, CA 92630 USA
 Tel (sales): +1 877 794 2622
 Email: sales@shrirousa.com
 Website: www.everdure.com

NOTES

EVERDURE

It is important that you retain these instructions, proof of purchase as well as other important documents about this product for future reference. Due to continual product development, Everdure reserves the right to alter specifications or appearances without notice.

Dispose of packaging responsibly - recycle where facilities are available.

SHRIRO USA INC. Incorporation Number 7164875

25541 Arctic Ocean Drive
Lake Forest, CA 92630 USA
Tel (toll free): +1 (877) 794 2622
Email: sales@shrirousa.com
Website: www.everdure.com