

MASTERBUILT®

MB20100922 Cart and Side Shelves

Portable Grill CGT18G1A



- Always remove plug from outlet before servicing your grill.
- Make sure your grill has fully cooled to avoid burns.
- Some components may have sharp edges. Use caution to avoid injury.
- Remove grate, manifold, and charcoal from your grill.



Note: It is recommended that you rotate your grill on it's side or upside down. To prevent scratching during the assembly, use cardboard or mat under your grill.



REMOVE THE GRILL SIDE HANDLES BEFORE ASSEMBLY

<p>1</p>	<p>2</p>	<p>3</p> <p>SOME PARTS MAY COME PRE-ASSEMBLED</p>
<p>Remove side handles, screws and mica plates.</p>	<p>Assemble the legs.</p>	<p>Attach wheels to the leg assembly.</p>
<p>4</p>	<p>5</p>	<p>6</p>
<p>Attach the brackets to the leg assembly.</p>	<p>Attach the cart latch to the grill body.</p>	<p>Attach the leg assembly to the grill body.</p>
<p>7</p>		<p>8</p>
<p>Install the left shelf.</p>		<p>Install the right shelf.</p>