Top Damper and Top Damper Plus Sizing Chart

Top Damper Size (in)	Fits INSIDE Flue Widths of (in)	Fits INSIDE Flue Lengths of (in)	Outside Base Dimensions (in)	Height of Damper When Open (in)	Height of Damper Lid Above Base of Damper Frame in Closed Position (in)	Height of the Damper from Base of the Damper to the top of the animal cap (in)
8 x 8	6" - 9"	6" - 9"	10" x 10"	7 1/2"	4"	11.5"
8 x 17	6" - 9"	14" - 17 1/2"	10" x 18"	8 1/4"	4"	11.5"
9 x 13	6" - 9 1/2"	9" - 12 1/2"	10" x 13"	10"	4"	11.5"
13 x 13	9" - 12 1/2"	9" - 12 1/2"	13" x 13"	10 1/4"	4"	11.5"
13 x 18	9" - 12 1/2"	14" - 17 1/2"	13" x 18"	8 1/2"	4"	11.5"
18 x 18	14" - 17 1/2"	14" - 17 1/2"	18" x 18"	8 1/4"	4"	11.5"