



Sinclair Single Panel Assembly Instructions

Parts Included

Frame x1

Front Legs x2

Back Legs x2


Bolts x4

Step 1

Place the Front Legs between the Inner Frame and Outer Frame. Align Front Legs to the outer most threaded holes closest to the sides of the Frame. Use supplied Allen wrench to tighten Bolts down.

Step 2

Align Back Legs to the inner most threaded holes. Use supplied Allen wrench to tighten Bolts down.



BACK OF SCREEN FRAME SHOWN IN ILLUSTRATION

PART# 18251
PART# 18323
PART# 18324